



## Engine starter Solenoid 1804A-24 24vdc Coil with emergency start

## lever

URL:https://www.sxplc.com/engine-startersolenoid-1804a-24-24vdc-coil-with-emergency-start-lever

## **Product data sheet**

Maximum coil current:24v units =10Amax

Contact voltage[] 30v DC (All models)

Contact rolling current: 1000A DC

Contact breakaway current: 2000A DC

